




Intertek

AIRREX[®]

AXIAL TURBO FAN

USER'S MANUAL

AF-2300(P)



- ▶ Thank you for purchasing the unit.
Before operation, please read this user's manual carefully.

TABLE OF CONTENTS

| | |
|------------------------|---|
| PRECAUTIONS BEFORE USE | 3 |
| EXTERIOR DESCRIPTION | 4 |
| SPECIFICATIONS | 5 |
| PRODUCT FEATURES | 6 |
| OPERATION | 6 |
| WARRANTY | 8 |

|  WARNING |  |  AVERTISSEMENT |
|--|---|--|
| <p>FIRE AND ELECTRIC SHOCK HAZARD</p> <p>Unit must be electrically grounded. Plug provided power cord only into outlet with Ground Fault Circuit Interrupting device. /Do not use adapter. /Never cut off third prong. /Do not use with extension cord.</p> <p>Keep motor and wiring dry.</p> <p>Use only for indoor usage. /When connecting to the outlet on the fan, turn off firstly. /Refer to MANUAL for more details. /Do not connect more than 8A when using the outlet on the fan. /Up to four products can be connected to outlet on the fan.</p> <p>To Reduce The Risk Of Electric Shock, Connect Only To An Outlet Provided With A Ground Fault Circuit Interrupting Device</p> | | <p>RISQUES D'INCENDIE ET DE CHOC ÉLECTRIQUE</p> <p>L'appareil doit être relié à la terre. Branchez le cordon d'alimentation fourni dans une prise DDFI (disjoncteur de fuite à la terre). /Ne pas utiliser d'adaptateur. /Ne coupez jamais la troisième broche de prise. /Ne pas utiliser avec une rallonge électrique.</p> <p>Garder le moteur et le câblage au sec.</p> <p>Utilisation à l'intérieur seulement. /Lorsque vous vous connectez à la prise du ventilateur, éteignez d'abord. /Voir le MANUEL pour plus de détails. /Ne pas connecter plus de 8A lorsque vous utilisez la sortie sur le ventilateur. /Jusqu'à quatre produits peuvent être raccordés à la sortie du ventilateur.</p> <p>Pour réduire le risque de choc électrique, connectez-vous seulement à un point de sortie fourni avec un dispositif d'interruption de circuit par défaut de sol</p> |

The following instructions are to ensure user's safety and to prevent any physical injury or material damage. Please read carefully and follow all instructions. There are two sections to these instructions: **WARNING** and **CAUTION**.

To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons,
 Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer
 (e.g. Parts Made At Home Using A 3D Printer).

- ▶ It is essential that you read 'SAFETY INSTRUCTIONS' carefully before use and follow them at all times.
- ▶ The warranty form is on the last page. Please complete it now and keep it in a safe place.
- ▶ Keep this manual on hand for reference.
- ▶ We have a policy of continual improving on our products. The contents (features and specifications) in this manual are therefore subject to change without notice.
- ▶ This unit is specified for use on the rated voltage power supply.

PRECAUTIONS BEFORE USE



Keep Children Away:

Do not allow children to play with or around the unit, which could result in injury. Be sure the unit is inaccessible to children when not attended.




Keep Unit Grounded:

Always operate the unit with a grounding plug and a grounded electrical outlet. A grounding plug is an essential safety feature that helps reduce the risk of shock or fire.



Protect Power Cord from Damage:

Never operate a unit with a damaged power cord, as this may lead to electrical or fire hazards. If the power supply cord is damaged, it must be replaced by a cord of the same type and amperage rating.



Extension Cords:

Do not use an extension cord.



3-Prong Plug:

Insert 3-prong plug on power cord only into outlet with Ground Fault Circuit Interrupting device.



Must not use outdoor.



Do Not Use Speed Control Device:

To reduce the risk of fire or electric shock, do not use TurboDryers with a solid-state speed control device.



Handle With Care:

Do not drop or throw the unit. Rough treatment can damage the components or wiring and create a hazardous condition.



Run on Stable Surface:

Always operate the unit on a stable, level surface, like the floor or a strong counter, so it cannot fall and cause injury.




Use Caution During Stacked Operation:

When stacking for operation, please use caution to avoid accident or injury from falling units. Avoid stacking units for operation in high-traffic areas. Keep children and pets away.




Secure During Transport:

When transporting in a vehicle, secure the unit to prevent sliding and possible injury to vehicle occupants.



Keep Out of Water:

Never operate the unit in pooled or standing water, as this may create a risk of injury from electrical shock. Do not store or operate outdoors. If electrical wiring or components become wet, thoroughly dry them before using the unit.




Keep Air Intakes Clear:

Do not clog or block air intakes, as may occur if operated too close to draperies or similar materials. This may cause the unit to overheat and result in a fire or electrical hazard.



Keep Out Dust and Dirt:

Do not allow dust, dirt, or other particles to be drawn into the air intakes. Dirt in the motor can cause it to overheat, resulting in a fire or electrical hazard. If the motor gets dirty, clean it using an air hose.



Unplug When Servicing:

Always unplug the unit before performing service or maintenance procedures.




Allow Repair Only by Qualified Person:

Do not attempt to dis-assemble or repair the unit if you are not qualified to do so. You may handle some maintenance and troubleshooting, but make sure that more complex problems are handled by an authorized service technician. For information about authorized repair, call SUNBELT.

EXTERIOR DESCRIPTION

EXTERIOR DESCRIPTION



SPECIFICATIONS


| MODEL | AF-2300(P) |
|--------------------|--|
| Dimensions (WxDxH) | 20 x 22 x 15.7 inch |
| Weight | 25.4 lbs. / 11.5 kg |
| Controls | 2-speed switch |
| CFM (CMM) | High : 1,932 (54.7) / Low : 1,417 (40.1) |
| Power | 115 V~, 60 Hz, 1 Ph |
| Current | 1.4 A |
| Fan blade | 16 inch (40.6 cm) |
| Power cord | 25 ft. (7.6 m) |
| Housing | Roto mould (LLDPE) |

PRODUCT FEATURES

- Very low amp draw
- 4 position versatility for handling a wide range of applications
- Dry quickly with high air flow
- Turn or tilt on non-slip rubber foot to switch operating positions
- Compact design that's stackable for storage
- Ideal for fast drying, carpet cleaning, ventilation



OPERATION



① Power ON/OFF switch (High/Low)

② Over current circuit breaker

③ Power Socket (Outlet)

MEMO

A large, empty rectangular box with a thin blue border, occupying most of the page, intended for writing the memo's content.

WARRANTY

(Applicable to first retail purchaser only)

AIRREX unit gives the more reliable performance, comfort and durability the more they are used. They are built under a strict quality assurance regime which includes inspection both during and after production and exhaustive reliability testing.

In the unlikely event you have any problems, please contact your dealer or distributor. If the problem is as a result of a production fault or failure, repairs will be undertaken free of charge during the period of warranty subject to the following warranty conditions:

1. If the problem has been caused by customer error or misuse, abuse or damage, then all repairs will be charged for.
2. This warranty applies to your country.
3. Proof and date of purchase must be supplied.
4. Please complete the details below and keep this warranty in a safe place.
5. All transportation charges back to the dealer are at customer's cost. Keep all original packaging to facilitate return. Return to customer will be at dealer's cost (if genuine warranty claim).

| | | | |
|-------------------------|-----------------|---------------------------|--|
| DESCRIPTION | AXIAL TURBO FAN | | |
| MODEL | AF-2300(P) | | |
| DATE OF PURCHASE | | PRODUCT SERIAL NO. | |
| WARRANTY PERIOD | () Months | | |
| DISTRIBUTOR | Name of Company | | |
| | Telephone No. | | |
| CUSTOMER DETAILS | Name : | | |
| | Address : | | |
| | Telephone : | | |

TEMP-AIR
EQUIPMENT SALES

www.tempsales.com

 2031 Exchange Parkway, Suite A, Waco, TX 76712

 888-535-8841

 sales@tempsales.com



US Electrical Standards
(ETL)